



# Use of Pedestals

<sup>1 2</sup><sub>3 4</sub> The code is unique for all port pedestals.

## 1. ACTIVATE THE SUPPLY

<sup>1 2</sup><sub>3 4</sub> Enter the code: 1-2-5-7-1-3 on the pedestal keypad.



The available plugs will flash on the keypad.



You have 10 seconds to choose the plug you wish to use.

## 2. CONNECT THE SERVICE



Select the plug, after selecting it you have 5 minutes to connect.

## 3. DEACTIVATE THE SUPPLY




Enter the code 1-2-5-7-1-3 again.




Select the plug to be deactivated and disconnect the cable.





# Use of Access Keyboards

 The access code is personal and non-transferable and you will receive it by e-mail or from the port administration.


## 1. ENTRANCE

 Enter your personal code on the keypad.


 If the code is accepted, the open padlock symbol lights up green and is accompanied by an acoustic signal.

 If there is no authorization for that sector, the closed padlock symbol lights up red and is accompanied by a flashing acoustic signal.

## 2. EXIT

 The exit from the pontoons is activated by pressing a green illuminated button on the first turret on the left side.

## 3. DRESSING ROOMS

 Re-enter your personal access code using the keypad located on the left side of the access door.